


Repair Parts for Brent Potter's Wheels



To find replacement parts other than full components, please contact an authorized Brent dealer nearest you. Many will also perform wheel repair.

Replacement parts listed here are for 110 volts only. If you are located outside North America, call (317) 244-6871 or (800) 374-1600 for help with Brent® wheel replacement parts.

Wheel Replacement Parts:

Wheel Replacement Parts are Found First By Selecting Your Controller Below!

When you are able to identify the controller presently attached to your Brent wheel model, we can correctly identify which replacement parts you need.

Whether you are looking for a replacement part for a controller (control box), a foot/hand pedal, a motor, wheelhead, belt, or fuse, you must first identify the controller for the wheel you have. Just take a minute to select your current controller on this page and follow our prompts!



To find replacement parts other than full components, please contact an authorized Brent dealer nearest you. Many will also perform wheel repair.

Replacement parts listed here are for 110 volts only. If you are located outside North America, call (317) 244-6871 or (800) 374-1600 for help with Brent® wheel replacement parts.

Wheel Replacement Parts



Step 1: Choose Your Controller
Selected (image at left)

Step 2: Choose Your Wheel
Now that you have identified your current controller, please click on the Brent Wheel Model that needs a replacement part from the list below:

brent B Potter's Wheel

Control Box (22141E)
Foot Pedal (22144H)
Wheel Head (22012M)
Belts {four groove} (22039X)
Fuse (22132S)
Splash Pan (22281F)
Leg Caps (22695P)

brent C Potter's Wheel

Control Box (22141E)
Foot Pedal (22144H)
Wheel Head (22017T)
Belts (22040Y)
Fuse (22133T)
Splash Pan (22281F)
Leg Caps (22695P)

To find replacement parts other than full components, please contact an authorized Brent dealer nearest you. Many will also perform wheel repair.

Replacement parts listed here are for 110 volts only. If you are located outside North America, call (317) 244-6871 or (800) 374-1600 for help with Brent® wheel replacement parts.

Wheel Replacement Parts



Step 1: Choose Your Controller
Selected (image at left)

Step 2: Choose Your Wheel
Now that you have identified your current controller,
please click on the Brent Wheel Model that needs a
replacement part from the list below:

brent B Potter's Wheel

Control Box (22599S)
Foot Pedal (22144H)
Wheel Head (22012M)
Belts {four groove} (22039X)
Fuse (22132S)
Splash Pan (22281F)
Leg Caps (22695P)

brent C Potter's Wheel

Control Box (22599S)
Foot Pedal (22144H)
Wheel Head (22017T)
Belts (22040Y)
Fuse (22133T)
Splash Pan (22281F)
Leg Caps (22695P)

brent CXC Potter's Wheel

Control Box (22599S)
Foot Pedal (22144H)
Wheel Head (22017T)
Belts (22040Y)
Fuse (22125J)
Splash Pan (22281F)

brent 16 Rehabilitation Wheel

Control Box (22599S)
Foot Pedal (22823B)
Wheel Head (22012M)
Belts {four groove} (22039X)
Fuse (22132S)
Splash Pan (22281F)

To find replacement parts other than full components, please contact an authorized Brent dealer nearest you. Many will also perform wheel repair.

Replacement parts listed here are for 110 volts only. If you are located outside North America, call (317) 244-6871 or (800) 374-1600 for help with Brent® wheel replacement parts.

Wheel Replacement Parts



Step 1: Choose Your Controller
Selected (image at left)

Step 2: Choose Your Wheel
Now that you have identified your current controller, please click on the Brent Wheel Model that needs a replacement part from the list below:

brent B Potter's Wheel

Control Box (22141E)
Foot Pedal (22144H)
Wheel Head (22012M)
Belts {four groove} (22039X)
Fuse (22132S)
Splash Pan (22281F)
Leg Caps (22695P)

brent Rehabilitation Wheel

Control Box (22141E)
Foot Pedal (22823B)
Wheel Head (22012M)
Belts {four groove} (22039X)
Fuse (22132S)
Splash Pan (22281F)

brent C Potter's Wheel

Control Box (22141E)
Foot Pedal (22144H)
Wheel Head (22017T)
Belts (22040Y)
Fuse (22133T)
Splash Pan (22281F)
Leg Caps (22695P)

brent ie/ie-r Potter's Wheel

Control Box (22799W)
Motor (22689H)
Foot Pedal (22144H)
Wheel Head (22012M)
Belts (22766F)
Fuse (22132S)
Splash Pan (22281F)

To find replacement parts other than full components, please contact an authorized Brent dealer nearest you. Many will also perform wheel repair.

Replacement parts listed here are for 110 volts only. If you are located outside North America, call (317) 244-6871 or (800) 374-1600 for help with Brent® wheel replacement parts.

Wheel Replacement Parts



Step 1: Choose Your Controller
Selected (image at left)

Step 2: Choose Your Wheel
Now that you have identified your current controller, please click on the Brent Wheel Model that needs a replacement part from the list below:

brent B Potter's Wheel

Control Box (22906Y)
Motor (22228N)
Foot Pedal (22035R)
Wheel Head (22012M)
Belts {four groove} (22039X)
Fuse (22924T)
Splash Pan (22281F)
Leg Caps (22695P)

brent C Potter's Wheel

Control Box (22907A)
Motor (22767G)
Foot Pedal (22035R)
Wheel Head (22017T)
Belts (22040Y)
Fuse (22924T)
Splash Pan (22281F)
Leg Caps (22695P)

brent 16 Rehabilitation Wheel

Control Box (22906Y)
Motor (22228N)
Foot Pedal (22035R)
Wheel Head (22012M)
Belts {four groove} (22039X)
Fuse (22125J)
Splash Pan (22281F)

brent CXC Potter's Wheel

Control Box (22908C)
Motor (22227M)
Foot Pedal (22035R)
Wheel Head (22017T)
Belts (22040Y)
Fuse (22924T)
Splash Pan (22281F)
Leg Caps (22695P)

brent EX Potter's Wheel

Control Box (22912F)
Motor (22786F)
Foot Pedal (22035R)
Wheel Head (22017T)
Belts (22040Y)
Fuse (22924T)
Splash Pan (22281F)
Leg Caps (22695P)

To find replacement parts other than full components, please contact an authorized Brent dealer nearest you. Many will also perform wheel repair. Replacement parts listed here are for 110 volts only. If you are located outside North America, call (317) 244-6871 or (800) 374-1600 for help with Brent® wheel replacement parts.
Wheel Replacement Parts

Wheel Replacement Parts



Step 1: Choose Your Controller
Selected (image at left)

Step 2: Choose Your Wheel
Now that you have identified your current controller, please click on the Brent Wheel Model that needs a replacement part from the list below:

brent B Potter's Wheel

Control Box (22906Y))
Motor (22228N)
Foot Pedal (22035R)
Wheel Head (22012M)
Belts {four groove} (22039X)
Fuse (22924T)
Splash Pan (22281F)
Leg Caps (22695P)

brent C Potter's Wheel

Control Box (22907A)
Motor (22767G)
Foot Pedal (22035R)
Wheel Head (22017T)
Belts (22040Y)
Fuse (22924T)
Splash Pan (22281F)
Leg Caps (22695P)

brent CXC Potter's Wheel

Control Box (22908C)
Motor (22227M)
Foot Pedal (22035R)
Wheel Head (22017T)
Belts (22040Y)
Fuse (22924T)
Splash Pan (22281F)
Leg Caps (22695P)

brent EX Potter's Wheel

Control Box (22912F)
Motor (22786F)
Foot Pedal (22035R)
Wheel Head (22017T)
Belts (22040Y)
Fuse (22924T)
Splash Pan (22281F)
Leg Caps (22695P)

brent 16 Rehabilitation Wheel

Control Box (22906Y)
Motor (22228N)
Foot Pedal (22035R)
Wheel Head (22012M)
Belts {four groove} (22039X)
Fuse (22924T)
Splash Pan (22281F)

brent ie-x Potter's Wheel

Motor (22765E)
Foot Pedal (22144H)
Wheel Head (22017T)
Belts (22766F)
Fuse (22132S)
Splash Pan (22281F)

To find replacement parts other than full components, please contact an authorized Brent dealer nearest you. Many will also perform wheel repair.

Replacement parts listed here are for 110 volts only. If you are located outside North America, call (317) 244-6871 or (800) 374-1600 for help with Brent® wheel replacement parts.

To find replacement parts other than full components, please contact an authorized Brent dealer nearest you. Many will also perform wheel repair.

Wheel Replacement Parts



Step 1: Choose Your Controller
Selected (image at left)

Step 2: Choose Your Wheel
Now that you have identified your current controller, please click on the Brent Wheel Model that needs a replacement part from the list below:

NOTE: Selected parts are no longer available for your control box configuration. To make your wheel operational, we will send you the appropriate modification kit.

brent B Potter's Wheel

Control Box (22599S)
Foot Pedal (22144H)
Wheel Head (22012M)
Belts {four groove} (22039X)
Fuse (22132S)
Splash Pan (22281F)
Leg Caps (22695P)

brent C Potter's Wheel

Foot Pedal (22144H)
Wheel Head (22017T)
Belts (22040Y)
Fuse (22133T)
Splash Pan (22281F)
Leg Caps (22695P)

brent 16 Rehabilitation Wheel

Control Box (22599S)
Foot Pedal (22823B)
Wheel Head (22012M)
Belts {four groove} (22039X)
Fuse (22132S)
Splash Pan (22281F)

brent CXC Potter's Wheel

Foot Pedal (22144H)
Wheel Head (22017T)
Belts (22040Y)
Fuse (22125J)
Splash Pan (22281F)
Leg Caps (22695P)

brent EX Potter's Wheel

Foot Pedal (22144H)
Wheel Head (22017T)
Belts (22040Y)
Fuse (22125J)
Splash Pan (22281F)
Leg Caps (22695P)

To find replacement parts other than full components, please contact an authorized Brent dealer nearest you. Many will also perform wheel repair.

Replacement parts listed here are for 110 volts only. If you are located outside North America, call (317) 244-6871 or (800) 374-1600 for help with Brent® wheel replacement parts.
To find replacement parts other than full components, please contact an authorized Brent dealer nearest you. Many will also perform wheel repair.

Wheel Replacement Parts



Step 1: Choose Your Controller
Selected (image at left)

Step 2: Choose Your Wheel
Now that you have identified your current controller, please click on the Brent Wheel Model that needs a replacement part from the list below:

NOTE: Selected parts are no longer available for your control box configuration. To make your wheel operational, we will send you the appropriate modification kit.

brent B Potter's Wheel

Foot Pedal (22895L)
Wheel Head (22012M)
Belts {four groove} (22039X)
Fuse (22132S)
Splash Pan (22281F)
Leg Caps (22695P)

brent CXC Potter's Wheel

Foot Pedal (22895L)
Wheel Head (22017T)
Belts (22040Y)
Fuse (22133T)
Splash Pan (22281F)
Leg Caps (22695P)

brent C Potter's Wheel

Foot Pedal (22895L)
Wheel Head (22017T)
Belts (22040Y)
Fuse (22133T)
Splash Pan (22281F)
Leg Caps (22695P)

brent EX Potter's Wheel

Foot Pedal (22895L)
Wheel Head (22017T)
Belts (22040Y)
Fuse (22133T)
Splash Pan (22281F)
Leg Caps (22695P)

brent 16 Rehabilitation Wheel

Splash Pan (22281F)

To find replacement parts other than full components, please contact an authorized Brent dealer nearest you. Many will also perform wheel repair.

Replacement parts listed here are for 110 volts only. If you are located outside North America, call (317) 244-6871 or (800) 374-1600 for help with Brent® wheel replacement parts. To find replacement parts other than full components, please contact an authorized Brent dealer nearest you. Many will also perform wheel repair.